


Connect your Vera to your local Wi-Fi hotspot

When your Vera is connected to your wifi in client mode, you can position the controller in any location in your home, without the inconvenience of an Ethernet cable

This guide will teach you:

- How to connect your Vera wirelessly to your local Wi-Fi hotspot



1. Open your **Vera UI7 Dashboard**
2. Open the **Settings** tab on the left menu
3. Press **Net & Wifi**
4. Select "**Through a Wi-Fi access point**"
5. Press "**Scan and connect to a wifi network**"
6. Wait for the nearby hotspots to appear on the list
7. Type in your passphrase and press "**Connect**"
8. After **5 seconds**, take the ethernet cable out of your Vera unit and **wait for the Service light to turn ON**

No#	Signal	Speed	Channel	SSID	BSSID	Encryption	Passphrase	
1		300 Mbps	1	mios_50	94:4A	WPA2	<input type="text"/>	Connect
2		300 Mbps	1	mios_55	B4:A5	WPA2	<input type="text"/>	Connect
3		300 Mbps	1	mios_50	E0:60	WPA2	<input type="text"/>	Connect
4		300 Mbps	8	TP-LINK	D4:6E	WPA2	<input type="text"/>	Connect
5		54 Mbps	9	TP-LINK	F4:F2	WPA2	<input type="text"/>	Connect